

USER MANUAL

GripFactory NanoGrip

Instructions for use on stone surfaces (tiles, concrete or natural stone)

1. Clean the surface with MicroGrip Cleaner and, if necessary, roughen it by sanding.
2. Make new tiles grease-free.
3. Clean old used and very dense tiles and flagstones and slightly acidify with MicroGrip Tiles, diluted 1 to 10 with water and rinse well and dry with a water vacuum cleaner.
4. Apply NanoGrip immediately after drying.
5. Thoroughly mix the two components with a spindle and immediately add the glass beads.
6. Apply NanoGrip with a fine-toothed comb or trowel in the layer thickness of the grain and immediately apply the structure with a yellow structure roller.

In the case of a glass surface, you must apply a Silane primer.

Note: At a temperature of 20°C, the processing time is approximately 45 minutes.

Drying times at 20°C/RH 50%

Tack-free	1 hour
Dry to handle	2 hours
Dry to recoat	5 hours
Fully cured	2 days

Application conditions

Minimum ambient temperature	5°C
Maximum relative humidity	85%
Minimum surface temperature	5°C
Maximum surface temperature	35°C
Cleaning equipment / splashes	Immediately after use with thinner.